



- 1 Position the interconnections (A) on the front face of the busbars as shown, starting with the neutral interconnection and secure using the M6 x 20 Hex. Hd. screws, nuts and washers provided.
- 2 Ensure all the interconnections are correctly aligned between the busbars and conform to the relevant diagram shown above.
- 3 Tighten all the M6 screws (recommended torque figure for M6 fasteners - 9NM).
- 4 Fit the M6 insulation caps over all the M6 nuts.

Note for MCFVK kit only:

The cross strap supplied with this kit should be used between the panel board units in place of the standard cross strap supplied with each unit.

This equipment must be installed in accordance with the requirements of all relevant legislation, regulations (including the latest edition of the IEE wiring regulations) and the accepted practice in the industry.